


Инструкция по использованию бас-гитарного звукоснимателя **EMG PHZ**

(на английском языке)



INSTALLATION INFORMATION EMG-HZ Model: P-HZ



Specifications:

Model:P-HZLogo ColorSilverInductance (Henries)3.0DC Resistance (K ohms)8.0Resonant Frequency (1)2550Resonant Frequency (2)4700Impedance @ Resonance (K ohm)(1)48.0

Notes:

(1) Loaded with 250K or 500K V @ T w/20' cable (800pf)

(2) Loaded with 1 Meg ohm/47pf

Each pickup includes:

4 pin cable pre-wired in Humbucking Series format. Adjustment screws

IMPORTANT INSTALLATION NOTES:

Recommended overall string width: 2.40"


Each pickup is mounted with 2 screws centered at each end.

The P-HZ is recommended for 4 string basses.




EMG-HZ Warranty:


All EMG-HZ Pickups and accessories are warranted for a period of two years. This warranty does not cover failure due to improper installation, abuse, or damage. If it any time a pickup fails to work, return it postage prepaid with proof of purchase. If upon examination the pickup is determined to be defective, a replacement will be mad at no charge. Warranty replacement products are covered under this same warranty. This warranty covers only those pickups and accessories sold by authorized EMG Dealers.



EMG-P-HZ Diagram 1 1 Volume only



EMG-P-HZ Diagram 2 1 Volume, 1 Tone



EMG-P-HZ Diagram 3 2 Volume, 1 Tone (each Volume is independent)

